



VIOLIN AND VIOLA CASES FOR CONCERT ARTISTS SINCE 1983
a division of Musafia Italia S.r.l. (Ltd)

DIGITAL THERMO-HYGROMETER

Instructions for Use

Updated March 28, 2011

The electronic thermometer-hygrometer in your Musafia case is a useful device which will help you care for your violin or viola. It is mounted inside the case in such a way to allow it to be easily detached for use outside of the case and in order to change the battery. Please keep these instructions handy for reference.

1) General use

- For acoustic string instruments, optimal relative humidity is between 40% and 70%. If humidity drops below these levels please use a humidifier to help ensure your instrument won't crack or unglue.
- The digital display can display the air temperature in Fahrenheit or Centigrade by briefly depressing the button on the left.
- The highest and lowest temperature and humidity are memorized and can be recalled by briefly depressing the button on the right.
- Holding the button on the right depressed for two seconds resets the memory feature.

2) How to detach the thermo-hygrometer from the case (if supplied installed in the case)

- Slip the elastic safety ribbon off.
- Slide the device upwards to unhook it from the screw that holds it in place

3) Characteristics

- Temperature and humidity readings updated every 10 sec.
- Thermometer readout in °C and °F, increments of 0.1 degrees
- Memory feature with min.- max. recording of both temperature and relative humidity
- Thermometer accuracy +/- 0.5°C circa; hygrometer accuracy +/- 3% circa
- Thermometer range: -10 C° to 50 °C (14°F to 122°F)
- Uses 1 AAA battery

Administration and Atelier: Via Novati, 4 26100 Cremona, Italy
tel. (+39) 0372-455047 (+39) 0372-454314 Fax (+39) 0372-454089 e-mail: info@musafia.com